







DOWNCONDUCTOR OPTIONS

TC-EC-2530-50
TC-EC-302-30
SC-EC-50
RC-EC-8

MAST OPTIONS



ERICO®

DYNASPHERE MKIV INSTALLATION GUIDE
FOR 3M GUYED MAST AND
CONVENTIONAL DOWNCONDUCTOR
DYNASPHERE MKIV GYD 1.DWG